



VENGEANCE[®]

RADIO CONTROLLED ALL-TERRAIN RACE CAR

OPERATING INSTRUCTIONS

Please read this entire insert before operating this product.



6
AGES



6
WAY



MEDIUM



HIGH SPEED



FULL FUNCTION
REMOTE CONTROL



CAUTION! ELECTRIC TOY: Not recommended for children under 6 years of ages. As with all electrical products, precautions should be observed during handling and use to reduce the risk of electrical shock.

ATTENTION PARENTS: It is recommended that this toy and all accessories be periodically examined for potential hazards and that any potentially hazardous parts be repaired or replaced.

CHARGING BATTERY PACK


IMPORTANT: New Battery pack is not fully-charged. Charge fully before first use.

Connect the wire plug of the battery pack to the wire plug of the charger.
Plug the charger into a standard 110/120V electrical outlet.
Charge for approximately 8 hours for the first time.
Subsequent recharges may require only 4-6 hours.
Unplug the charger from the outlet and detach the wire plug connectors.

NOTE: Do not pull on wires, as they may come loose from the plug connectors.

BATTERY REQUIREMENTS:

Car: 1 x "9.6V" NiCd rechargeable battery pack (included)
Remote Transmitter: 1 x "9V" battery (included)



REMOTE TRANSMITTER SET-UP

1. Remove the battery cover on the bottom of the transmitter. Insert 1 "9V" battery into the compartment and replace the battery cover.
2. Insert the antenna to the top of the transmitter and screw in tightly.
3. Switch the power switch to the "ON" position



1 "9V" Battery




CAR SET-UP

Remove the battery cover on the bottom of the car.

Install the battery pack by connecting the wire plug from the car to the wire plug on the battery pack. Insert the battery pack into the bottom of the car and replace the battery cover.

Switch the power switch on the bottom of the car to the "ON" position.




Steering alignment lever

OPERATIONS

1. Place the car on a smooth, flat surface and extend antenna fully on the remote controller.
2. To move the car forward in a straight line pull trigger back with finger.
3. To move the car backward in a straight line push trigger forward with finger.
4. To turn the car right, turn the steering wheel on the side of the remote controller clockwise.
5. To turn the car left, turn the steering wheel on the side of the remote controller counter-clockwise.

NOTE: For maximum performance, hold the transmitter upright so the antenna points up (do not point the antenna at the car, this will reduce the signal range).



6. Adjust the steering alignment lever located on the bottom of the car (between front wheels). If the car does not run straight when moving forward (refer to drawing on the Car Set Up section for location of the steering alignment lever).

TROUBLE-SHOOTING

PROBLEM

Car does not move or runs slowly

PROBABLE SOLUTIONS

- Make sure power switch on car and transmitter are in the "ON" position
- Make sure the batteries in the car and transmitter are installed properly
- Recharge car's NiCd battery pack or replace if it necessary
- Replace 9V battery in transmitter with fresh alkaline battery

Car moves erratically or transmitter range is short

- Change locations as there may be radio interference in the area
- Move away from other remote control cars as they may be operating on the same frequency
- Make sure antenna in transmitter is screwed in tight and fully extended
- Make sure transmitter battery connections are in good condition and replace battery

Car does not work after going through water or snow

- Allow car to dry thoroughly overnight
- Avoid driving in water or snow

SAFETY PRE-CAUTIONS

- Do not operate during thunderstorms or rain.
- Avoid water, sand and snow when operating your car.
- Do not submerge car or controller in water.
- Never operate your car on the street or highway.
- Never operate your car in a confined or crowded area, and do not use people or animals as obstacles.
- Do not run your car into furniture, objects or hard surfaces, as this will cause damage to both the objects and the car.
- Keep fingers, hair and loose clothing away from the tires, gears and motor while the car is switched to "ON".
- Do not leave car or transmitter near sources of heat or under direct sunlight for long periods of time.
- Do not leave car or transmitter outside overnight. Dampness is harmful to interior components.
- Remove all batteries when not in use to avoid accidental operation.
- **Adult supervision is recommended when operating this car.**

BATTERY PRE-CAUTIONS

THIS PRODUCT USES A NICKEL-CADMIUM (NiCd) RECHARGEABLE BATTERY PACK.
BATTERY MUST BE RECYCLED OR DISPOSED OF PROPERLY ACCORDING TO INDIVIDUAL STATE OR LOCAL GOVERNMENT REGULATIONS.

- Batteries should be inserted with the correct polarity.
- Do not short circuit battery contacts.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadium) batteries.
- Remove batteries if car will not be used for a long period.
- Check the batteries regularly for leakage.
- Exhausted batteries should be removed from the charger.
- Do not dispose batteries in a fire - batteries may leak or explode.
- Use only the recommended batteries or batteries of equal quality/type.
- Do not recharge non-rechargeable batteries.
- Remove battery pack from car before recharging.
- Do not pull on wires when detaching the battery pack plug/connector.
- Do not recharge warm or hot battery packs - wait until pack has cooled down.
- Do not overcharge - this may damage the battery pack.
- Recharging too early will shorten battery pack life.
- Do not recharge batteries that show wear or leakage.
- Do not recharge in high temperatures or bring the battery pack near a flame.
- Do not let the charger or battery pack get wet or damp.
- Do not take the charger or battery pack apart.
- Rechargeable batteries should always be charged under adult supervision.

BATTERY WARNING:

- Do NOT mix alkaline, standard (carbon-zinc) and rechargeable (Nickel Hydride) batteries.
- Do NOT mix old and new batteries
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the item before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Exhausted batteries should be removed.
- The supply terminals are NOT to be short-circuited.
- Only batteries of the same or equivalent type as recommended to be used.
- Batteries are to be inserted with the correct polarity.

****CONTAINS NICKEL-CADMIUM BATTERY****

BATTERY MUST BE RECYCLED OR DISPOSED OF PROPERLY.



Ni-Cd

CAUTION

- Do not short circuit supply terminals.
- Do not dispose of battery in fire
- Remove battery from toy when not in use.
- Do not attempt to open battery.
- Do not recharge battery that shows leakage or corrosion.
- Dispose of battery safely.

KEEP THIS INSERT FOR REFERENCE SINCE IT CONTAINS IMPORTANT INFORMATION

RADIO CONTROL

NOT SUITABLE FOR CHILDREN UNDER 6 YEARS OF AGE



©2009 MerchSource, LLC. All rights reserved.
Distributed by MerchSource, LLC, Foothill Ranch, CA 92610.

Blue Hat Toy Company and the Blue Hat Toy Company logos are registered trademarks of MerchSource, LLC.

Vengeance is a registered trademark of Merchsource, LLC.

Patent Pending

The artwork and design of this manual are protected by US copyright law and may not be reproduced, distributed, displayed, published or used for any purpose without prior written permission. It is not permitted to alter, remove or reproduce any trademarks or copyright notice from this manual.

PRINTED IN CHINA