

OPERATING INSTRUCTIONS



SAFETY PRECAUTIONS

- Do not operate during thunderstorms or rain.
- Avoid water, sand and snow when operating your car.
- Do not submerge car or controller in water.
- Never operate your car on the street or highway.
- Adult supervision is recommended when operating this car.
- Remove all batteries when not in use to avoid accidental operation.
- Never operate your car in a confined or crowded area, and do not use people or animals as obstacles.
- Do not run your car into furniture, objects or hard surfaces, as this will cause damage to both the objects and the car.
- Keep fingers, hair and loose clothing away from the tires, gears and motor while the car is switched to "ON".
- Do not leave car or transmitter near sources of heat or under direct sunlight for long periods of time.
- Do not leave car or transmitter outside overnight. Dampness is harmful to interior components.

BATTERY INFORMATION

- Operation requires 3 "AA" batteries (not included) for car and one 9V battery (included) for radio controller.
- Carefully remove items from packaging.
 - Refer to the diagram below for battery installation. Unscrew with a Phillips screw driver and rotate lever (A) to unlock the battery door (B). Open the battery door (B), insert 3 "AA" size batteries in the correct polarity shown (C). Close and screw back to close the battery door.
 - Slide open the battery compartment door on the back of the controller. Insert one 9V battery following the correct polarity. Replace the battery compartment door.

- **NOTE:** All turning is performed by back wheels.

CAUTION:
Do not place hands on or near back of car during transforming to avoid potential pinching.

KEEP THIS PACKAGING FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.



MODES:

ROBOT MODE



RACE CAR MODE



DO NOT OPERATE BETWEEN MODES



BATTERY INSTALLATION



LIFT BACK UPWARDS TO ACCESS BATTERY COMPARTMENT

REQUIRES 3 "AA" BATTERIES (NOT INCLUDED).

